

PL-TR-95-2037(II)

CIRRIS 1A POST FLIGHT CALIBRATION

Gail Bingham
James Peterson
Steven Brown
David Morse
Brent Bartschi
Allan Steed

Space Dynamics Laboratory/Utah State University
Logan, Utah 84322

January 1995

Final Report (Volume II)
3 June 1981 - 31 May 1994

Approved for public release; distribution unlimited



PHILLIPS LABORATORY
Directorate of Geophysics
AIR FORCE MATERIEL COMMAND
HANSCOM AFB, MA 01731-3010

19961220 115

"This technical report has been reviewed and is approved for publication"

Richard M. Nadile
(Signature)
Richard M. Nadile
Contract Manager

Stephen Price
(Signature)
Dr. Stephen D. Price
Branch Chief

Roger A. Van Tassel
(Signature)
Dr. Roger A. Van Tassel
Division Director

This report has been reviewed by the ESC Public Affairs Office (PA) and is releasable to the National Technical Information Service (NTIS).

Qualified requestors may obtain additional copies from the Defense Technical Information Center (DTIC). All others should apply to the National Technical Information Service (NTIS).

If your address has changed, if you wish to be removed from the mailing list, or if the addressee is no longer employed by your organization, please notify PL/IM, 29 Randolph Road, Hanscom AFB, MA 01731-3010. This will assist us in maintaining a current mailing list.

Do not return copies of this report unless contractual obligations or notices on a specific document requires that it be returned.

REPORT DOCUMENTATION PAGE

Form Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing the burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

1. AGENCY USE ONLY (Leave blank)	2. REPORT DATE	3. REPORT TYPE AND DATES COVERED
	January 1995	Final Vol II (3 Jun 1981-31 May 1994)
4. TITLE AND SUBTITLE		5. FUNDING NUMBERS
CIRRIS 1A Post Flight Calibration		PE 62101F PR 7670 TA 10 WU AI
6. AUTHOR(S)		Contract F19628-81-C-0123
Gail Bingham James Peterson Steven Brown		David Morse Brent Bartschi Allan Steed
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)		8. PERFORMING ORGANIZATION REPORT NUMBER
Space Dynamics Laboratory Utah State University Logan, Utah 84341		SDL/92-091
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)		10. SPONSORING/MONITORING AGENCY REPORT NUMBER
Phillips Laboratory 29 Randolph Road Hanscom AFB, MA 01731-3010 Contract Manager: Richard Nadile (GPOB)		PL-TR-95-2037 (II)
11. SUPPLEMENTARY NOTES		
12a. DISTRIBUTION/AVAILABILITY STATEMENT		12b. DISTRIBUTION CODE
Approved for public release; distribution unlimited		
13. ABSTRACT (Maximum 200 words)		
<p>The Cryogenic Infrared Radiance Instrumentation for Shuttle (CIRRIS 1A) instrument is a state-of-the-art cryogenically cooled instrument designed to observe the infrared spectrum of the earth's atmosphere. The Space Dynamics Laboratory at Utah State University (SDL/USU) participated as the prime contractor in this program. CIRRIS 1A was launched on the shuttle Discovery (STS-39) on 28 April 1991. All of the instruments operated as designed during the mission. Data obtained from this experiment will help refine knowledge of the background radiance and structure of atmospheric infrared emissions, and will be used to update and validate U.S. Air Force atmospheric models used in the design of operational systems. SDL/USU performed a complete ground calibration of the primary and ancillary sensors to verify instrument design and to create algorithms necessary for post flight data reduction. This report represents Volume 2 of the CIRRIS 1A Post Flight Calibration Final Report. Volume 2 contains reduced data for various parameters for all of the detectors. Volume 1 describes the calibration approach, discusses the results of the calibration, and provides graphical data for the primary detectors of each sensor. General descriptions of the radiometer and interferometer are also included.</p>		
14. SUBJECT TERMS		15. NUMBER OF PAGES
CIRRIS 1A, calibration, radiometer, interferometer, infrared, shuttle		78
		16. PRICE CODE
17. SECURITY CLASSIFICATION OF REPORT	18. SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICATION OF ABSTRACT
Unclassified	Unclassified	Unclassified
20. LIMITATION OF ABSTRACT		SAR

LIST OF FIGURES

	<u>Page</u>
Jones source maps for radiometer detectors 1-1 and 1-2	1
Jones source maps for radiometer detectors 1-3 and 1-4	2
Jones source maps for radiometer detectors 1-5 and 1-6	3
Jones source maps for radiometer detectors 1-7 and 1-8	4
Jones source maps for radiometer detectors 2-1 and 2-2	5
Jones source maps for radiometer detectors 2-3 and 2-4	6
Jones source maps for radiometer detectors 2-5	7
Relative spectral response for radiometer detector 1-4	16
Relative spectral response for radiometer focal plane 2	18
Radiometer out-of-band rejection, focal plane 1, filter 0	19
Radiometer out-of-band rejection, focal plane 1, filter 1	19
Radiometer out-of-band rejection, focal plane 1, filter 2	20
Radiometer out-of-band rejection, focal plane 1, filter 3	20
Radiometer out-of-band rejection, focal plane 1, filter 5	21
Radiometer out-of-band rejection, focal plane 1, filter 7	21
Radiometer out-of-band rejection, focal plane 2	22
RMS noise history for radiometer detector 1-1	23
RMS noise history for radiometer detector 1-2	24
RMS noise history for radiometer detector 1-3	25
RMS noise history for radiometer detector 1-4	26
RMS noise history for radiometer detector 1-5	27
RMS noise history for radiometer detector 1-6	28
RMS noise history for radiometer detector 1-7	29
RMS noise history for radiometer detector 1-8	30
RMS noise history for radiometer detector 2-1	31
RMS noise history for radiometer detector 2-2	32
RMS noise history for radiometer detector 2-3	33
RMS noise history for radiometer detector 2-4	34
RMS noise history for radiometer detector 2-5	35
Offset history for radiometer detector 1-1	36

Offset history for radiometer detector 1-2.	37
Offset history for radiometer detector 1-3.	38
Offset history for radiometer detector 1-4.	39
Offset history for radiometer detector 1-5.	40
Offset history for radiometer detector 1-6.	41
Offset history for radiometer detector 1-7.	42
Offset history for radiometer detector 1-8.	43
Offset history for radiometer detector 2-1.	44
Offset history for radiometer detector 2-2.	45
Offset history for radiometer detector 2-3.	46
Offset history for radiometer detector 2-4.	47
Offset history for radiometer detector 2-5.	48
Radiometer noise flux versus band pass for filter 0 (chopper on, extended area source - order on curve labels is bias - gain).	49
Radiometer noise flux versus band pass for filter 0 (chopper on, extended area source - order on curve labels is bias - gain).	50
Radiometer noise flux versus band pass for filter 1 (chopper on, extended area source - order on curve labels is bias - gain).	51
Radiometer noise flux versus band pass for filter 1 (chopper on, extended area source - order on curve labels is bias - gain).	52
Radiometer noise flux versus band pass for filter 2 (chopper on, extended area source - order on curve labels is bias - gain).	53
Radiometer noise flux versus band pass for filter 2 (chopper on, extended area source - order on curve labels is bias - gain).	54
Radiometer noise flux versus band pass for filter 3 (chopper on, extended area source - order on curve labels is bias - gain).	55
Radiometer noise flux versus band pass for filter 3 (chopper on, extended area source - order on curve labels is bias - gain).	56
Radiometer noise flux versus band pass for filter 5 (chopper on, extended area source - order on curve labels is bias - gain).	57
Radiometer noise flux versus band pass for filter 5 (chopper on, extended area source - order on curve labels is bias - gain).	58
Radiometer noise flux versus band pass for filter 6 (chopper on, extended area source - order on curve labels is bias - gain).	59
Radiometer noise flux versus band pass for filter 6 (chopper on, extended area source - order on curve labels is bias - gain).	60

Radiometer noise flux versus band pass for filter 7 (chopper on, extended area source - order on curve labels is bias - gain).	61
Radiometer noise flux versus band pass for filter 7 (chopper on, extended area source - order on curve labels is bias - gain).	62
Radiometer noise flux versus band pass (chopper on, extended area source - order on curve labels is bias - gain).	63
Radiometer noise flux versus band pass (chopper on, extended area source - order on curve labels is bias - gain).	64
RMS noise history for interferometer detector 1.	65
RMS noise history for interferometer detector 2.	65
RMS noise history for interferometer detector 3.	66
RMS noise history for interferometer detector 4.	66
RMS noise history for interferometer detector 5.	67
Offset history for interferometer detector 1.	68
Offset history for interferometer detector 2.	68
Offset history for interferometer detector 3.	69
Offset history for interferometer detector 4.	69
Offset history for interferometer detector 5.	70


FOREWORD

The Cryogenic Infrared Radiance Instrumentation for Shuttle (CIRRIS 1A) program, sponsored by the Strategic Defense Initiative Organization (SDIO) and managed by the Geophysics Directorate of the USAF Phillips Laboratory, is a state-of-the-art cryogenically cooled instrument designed to observe the infrared spectrum of the earth's atmosphere. The Space Dynamics Laboratory at Utah State University (SDL/USU) was awarded contract no. F19628-81-C-0123 to participate as the prime contractor in this program. As part of this program, SDL designed, constructed, calibrated, tested, and integrated primary and support instruments for the CIRRIS 1A experiment. In addition, SDL personnel provided mission support and documentation, including flight crew training. CIRRIS 1A was launched on the space shuttle Discovery on 28 April 1991. All of the instruments operated as designed during the mission.

This report, submitted in compliance with CDRL 160, presents the results of the CIRRIS 1A post flight calibration. This document represents the current understanding of the CIRRIS 1A calibration accuracy and applicability to the data collected during the CIRRIS mission. Several drafts of this report were previously submitted for review; this document is the final submission. The calibration coefficients will continue to be refined as the flight data are further analyzed.

This document represents Volume 2 of the CIRRIS 1A Post Flight Calibration Final Report. This volume contains reduced data for various parameters for all of the detectors. The calibration approach and results are presented in Volume 1.

SDL/USU would like to acknowledge Boston College, Miranda Laboratories, and PhotoMetrics for alignment and pointing data, and coding of OPUS.




DESCRIPTION

Detector : 1-1L
 Starting X : 0.00
 Starting Y : -240.00
 Number of X : 21
 Number of Y : 31
 Det X : 5.00
 Det Y : 5.00
 Min lnum : 0.00000
 Max lnum : 0.14199
 D: \RPSMAP10\N10D11L

DESCRIPTION

Detector : 1-2L
 Starting X : 0.00
 Starting Y : -240.00
 Number of X : 21
 Number of Y : 31
 Det X : 5.00
 Det Y : 5.00
 Min lnum : 0.00009
 Max lnum : 0.13251
 D: \RPSMAP10\N10D12L


Jones source maps for radiometer detectors 1-1 and 1-2.



DESCRIPTION
 Detector : 1-3L
 Starting X: 0.00
 Starting Y: -240.00
 Number of X: 21
 Number of Y: 31
 Delta X: 5.00
 Delta Y: 5.00
 Min lnum: 0.00008
 Max lnum: 0.12249
 D: \RPSMAP10\M10D13L

DESCRIPTION
 Detector : 1-4L
 Starting X: 0.00
 Starting Y: -240.00
 Number of X: 21
 Number of Y: 31
 Delta X: 5.00
 Delta Y: 5.00
 Min lnum: 0.00013
 Max lnum: 0.14037
 D: \RPSMAP10\M10D14L

Jones source maps for radiometer detectors 1-3 and 1-4.




DESCRIPTION

Detector ... 1-5L
 Starting X ... 0.00
 Starting Y ... -240.00
 Number of X ... 21
 Number of Y ... 31
 Det X ... 5.00
 Det Y ... 5.00
 Min lnum ... 0.00079
 Max lnum ... 0.12647
 D:\RPSMAP10\Y10D15L

DESCRIPTION

Detector ... 1-6L
 Starting X ... 0.00
 Starting Y ... -240.00
 Number of X ... 21
 Number of Y ... 31
 Det X ... 5.00
 Det Y ... 5.00
 Min lnum ... 0.00013
 Max lnum ... 0.12991
 D:\RPSMAP10\Y10D16L

Jones source maps for radiometer detectors 1-5 and 1-6.




DESCRIPTION

Detector ... 1-7L
 Starting X... 0.00
 Starting Y... -240.00
 Number of X... 21
 Number of Y... 31
 Det X..... 5.00
 Det Y..... 5.00
 Min lnum -0.00024
 Max lnum 0.01079
 D:\RPSMAP10\MI0D17L

DESCRIPTION

Detector ... 1-8L
 Starting X... 0.00
 Starting Y... -240.00
 Number of X... 21
 Number of Y... 31
 Det X..... 5.00
 Det Y..... 5.00
 Min lnum -0.00018
 Max lnum 0.01789
 D:\RPSMAP10\MI0D18L


Jones source maps for radiometer detectors 1-7 and 1-8.



DESCRIPTION

Detector	2-1H
Starting X	0.00
Starting Y	-240.00
Number of X	21
Number of Y	31
Detector X	31
Detector Y	5.00
Detector X	5.00
Detector Y	5.00
Min Lnum	-0.00277
Max Lnum	0.29134
D:\RPSMAP10\m10D21	

Jones source maps for radiometer detectors 2-1 and 2-2.




DESCRIPTION

Detector : 2-3H
 Starting X.: 0.00
 Starting Y.: -240.00
 Number of X.: 21
 Number of Y.: 31
 Det. X.: 5.00
 Det. Y.: 5.00
 Min. lnum : -0.00277
 Max. lnum : 0.19387
 D: \RPSMAP10\m10D23

DESCRIPTION

Detector : 2-4H
 Starting X.: 0.00
 Starting Y.: -240.00
 Number of X.: 21
 Number of Y.: 31
 Det. X.: 5.00
 Det. Y.: 5.00
 Min. lnum : -0.00331
 Max. lnum : 0.03585
 D: \RPSMAP10\m10D24

Jones source maps for radiometer detectors 2-3 and 2-4.



DESCRIPTION

Detector ...: 2-5H
 Starting X...: 0.00
 Starting Y...: -240.00
 Number of X: 21
 Number of Y: 31
 Delta X...: 5.00
 Delta Y...: 5.00
 Min Lnum: -0.00305
 Max Lnum: 0.13269
 D:\RPSMAP10\N10D25f

Jones source maps for radiometer detectors 2-5.

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 0, bandpass, linear fit)

DET	BIAS	GAIN	A1	A2	S.D.	MIN.	VOLT.	MAX. VOLT.
1-1	HI	LO	4.04044E+00	-4.06883E-01	1.97368E-04	5.90900E-04	1.59300E+00	
1-2			2.15022E+00	-2.16524E-01	1.97925E-04	5.90900E-04	1.59300E+00	
1-3			4.86650E+00	-4.90052E-01	1.97816E-04	5.90900E-04	1.59300E+00	
1-4			2.07024E+00	-2.08483E-01	1.97037E-04	5.90900E-04	1.59300E+00	
1-5			5.00050E+00	-5.03538E-01	1.98077E-04	5.90900E-04	1.59300E+00	
1-6			2.03032E+00	-2.04303E-01	1.60217E-02	5.90900E-04	1.59300E+00	
1-7			7.39075E+01	-7.44237E+00	1.97930E-04	5.90900E-04	1.59300E+00	
1-8			1.75018E+01	-1.76244E+00	1.97691E-04	5.90900E-04	1.59300E+00	
1-1	HI	HI	4.07042E-02	-4.09890E-03	1.97782E-04	5.90900E-04	1.59300E+00	
1-2			2.50027E-02	-2.51783E-03	1.97397E-04	5.90900E-04	1.59300E+00	
1-3			5.00054E-02	-5.03565E-03	1.97397E-04	5.90900E-04	1.59300E+00	
1-4			2.14022E-02	-2.15520E-03	1.97737E-04	5.90900E-04	1.59300E+00	
1-5			5.30055E-02	-5.33764E-03	1.97733E-04	5.90900E-04	1.59300E+00	
1-6			2.13023E-02	-2.14517E-03	1.97491E-04	5.90900E-04	1.59300E+00	
1-7			7.60085E-01	-7.65435E-02	1.97162E-04	5.90900E-04	1.59300E+00	
1-8			1.95020E-01	-1.96384E-02	1.97798E-04	5.90900E-04	1.59300E+00	
1-1	MED	LO	3.03414E+01	0.00000E+00	3.13351E-03	1.49600E-01	6.12700E-01	
1-2			1.71432E+01	0.00000E+00	3.10408E-03	2.72600E-01	1.09300E+00	
1-3			3.16675E+01	0.00000E+00	1.10090E-02	1.43500E-01	5.86800E-01	
1-4			1.57333E+01	0.00000E+00	4.32499E-03	2.98000E-01	1.19200E+00	
1-5			3.60025E+01	0.00000E+00	2.35026E-03	1.26700E-01	5.17200E-01	
1-6			1.51775E+01	0.00000E+00	1.06077E-02	3.14700E-01	1.80100E+00	
1-7			5.84064E+02	0.00000E+00	6.15571E-03	8.06100E-03	4.67200E-02	
1-8			1.16936E+02	0.00000E+00	2.67001E-03	3.83000E-02	2.31100E-01	
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-1	LO	LO	2.89243E+02	0.00000E+00	1.91450E-02	9.81800E-02	2.27600E+00	
1-2			1.60492E+02	0.00000E+00	1.54137E-02	1.74400E-01	1.97400E+00	
1-3			3.13617E+02	0.00000E+00	3.04576E-02	9.05800E-02	2.09500E+00	
1-4			1.46450E+02	0.00000E+00	1.95774E-02	1.87300E-01	2.16500E+00	
1-5			3.46726E+02	0.00000E+00	3.67822E-02	8.16700E-02	1.89400E+00	
1-6			1.41526E+02	0.00000E+00	7.86006E-03	2.92700E-01	2.25100E+00	
1-7			5.89601E+03	0.00000E+00	5.77316E-02	1.81800E-02	1.32600E+00	
1-8			1.11848E+03	0.00000E+00	3.80401E-02	3.75300E-02	2.17600E+00	
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 1, bandpass, linear fit)

DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
1-1	HI	LO	2.80030E+01	-2.81996E+00	1.97384E-04	5.90900E-04	1.59300E+00
1-2			1.55017E+01	-1.56104E+00	1.97421E-04	5.90900E-04	1.59300E+00
1-3			3.97043E+01	-3.99830E+00	1.97423E-04	5.90900E-04	1.59300E+00
1-4			1.55017E+01	-1.56104E+00	1.97421E-04	5.90900E-04	1.59300E+00
1-5			4.14044E+01	-4.16949E+00	1.97512E-04	5.90900E-04	1.59300E+00
1-6			1.67018E+01	-1.68191E+00	1.97469E-04	5.90900E-04	1.59300E+00
1-7			6.27063E+02	-6.31440E+01	1.98031E-04	5.90900E-04	1.59300E+00
1-8			1.25014E+02	-1.25894E+01	1.97146E-04	5.90900E-04	1.59300E+00
1-1	HI	HI	2.80033E-01	-2.82011E-02	1.96884E-04	5.90900E-04	1.59300E+00
1-2			1.59017E-01	-1.60134E-02	1.97363E-04	5.90900E-04	1.59300E+00
1-3			3.90040E-01	-3.92769E-02	1.97798E-04	5.90900E-04	1.59300E+00
1-4			1.48016E-01	-1.49055E-02	1.97410E-04	5.90900E-04	1.59300E+00
1-5			4.20045E-01	-4.22995E-02	1.97428E-04	5.90900E-04	1.59300E+00
1-6			1.62018E-01	-1.63155E-02	1.97374E-04	5.90900E-04	1.59300E+00
1-7			6.40069E+00	-6.44564E-01	1.97397E-04	5.90900E-04	1.59300E+00
1-8			1.35015E+00	-1.35968E-01	1.96995E-04	5.90900E-04	1.59300E+00
1-1	MED	LO	2.35997E+02	0.00000E+00	2.79648E-03	9.06500E-02	2.07600E-01
1-2			1.30052E+02	0.00000E+00	3.13445E-03	1.64400E-01	3.76600E-01
1-3			2.93441E+02	0.00000E+00	2.63949E-03	7.30400E-02	1.67100E-01
1-4			1.25395E+02	0.00000E+00	2.83262E-03	1.70000E-01	3.90100E-01
1-5			3.26714E+02	0.00000E+00	2.26316E-03	6.56100E-02	1.50100E-01
1-6			1.31515E+02	0.00000E+00	3.78212E-03	1.61400E-01	3.71200E-01
1-7			5.34756E+03	0.00000E+00	4.22618E-03	4.02300E-03	9.18200E-03
1-8			9.20928E+02	0.00000E+00	3.87946E-03	2.28700E-02	5.28300E-02
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	LO	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 2, bandpass, linear fit)

DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
1-1	HI	LO	1.33714E+01	-1.34651E+00	1.97620E-04	5.90900E-04	1.59300E+00
1-2			7.25076E+00	-7.30156E-01	1.97613E-04	5.90900E-04	1.59300E+00
1-3			1.80019E+01	-1.81282E+00	1.97455E-04	5.90900E-04	1.59300E+00
1-4			6.90067E+00	-6.94871E-01	1.98314E-04	5.90900E-04	1.59300E+00
1-5			1.82020E+01	-1.83299E+00	1.97327E-04	5.90900E-04	1.59300E+00
1-6			7.40082E+00	-7.45290E-01	1.97228E-04	5.90900E-04	1.59300E+00
1-7			2.99033E+02	-3.01135E+01	1.97265E-04	5.90900E-04	1.59300E+00
1-8			6.00063E+01	-6.04266E+00	1.97633E-04	5.90900E-04	1.59300E+00
1-1	HI	HI	1.38014E-01	-1.38979E-02	1.97872E-04	5.90900E-04	1.59300E+00
1-2			7.20077E-02	-7.25131E-03	1.97468E-04	5.90900E-04	1.59300E+00
1-3			1.80019E-01	-1.81278E-02	1.97757E-04	5.90900E-04	1.59300E+00
1-4			7.10068E-02	-7.15008E-03	1.98484E-04	5.90900E-04	1.59300E+00
1-5			1.87020E-01	-1.88330E-02	1.97654E-04	5.90900E-04	1.59300E+00
1-6			7.40080E-02	-7.45275E-03	1.97410E-04	5.90900E-04	1.59300E+00
1-7			3.00033E+00	-3.02140E-01	1.97367E-04	5.90900E-04	1.59300E+00
1-8			6.50067E-01	-6.54615E-02	1.97751E-04	5.90900E-04	1.59300E+00
1-1	MED	LO	1.11696E+02	0.00000E+00	3.21374E-03	1.16300E-01	6.17400E-01
1-2			6.13877E+01	0.00000E+00	3.01686E-03	2.13800E-01	1.12600E+00
1-3			1.31834E+02	0.00000E+00	4.19463E-03	9.78100E-02	5.22300E-01
1-4			5.77732E+01	0.00000E+00	8.64858E-03	2.25400E-01	1.19600E+00
1-5			1.43980E+02	0.00000E+00	1.38927E-03	9.06200E-02	4.79400E-01
1-6			5.99653E+01	0.00000E+00	5.20095E-03	4.03800E-01	1.81500E+00
1-7			2.55910E+03	0.00000E+00	1.60595E-03	9.25800E-03	4.23100E-02
1-8			4.42348E+02	0.00000E+00	3.37276E-03	5.17800E-02	2.42900E-01
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	LO	1.04860E+03	0.00000E+00	9.60681E-03	1.02700E-01	1.11300E+00
1-2			5.78827E+02	0.00000E+00	1.80986E-03	1.87400E-01	2.03100E+00
1-3			1.26108E+03	0.00000E+00	5.18505E-03	8.61500E-02	9.31900E-01
1-4			5.34755E+02	0.00000E+00	4.64426E-03	1.98000E-01	2.19400E+00
1-5			1.33989E+03	0.00000E+00	6.63744E-03	7.98600E-02	8.74100E-01
1-6			5.64736E+02	0.00000E+00	5.48157E-03	3.00000E-01	2.08800E+00
1-7			2.32690E+04	0.00000E+00	4.17668E-03	7.08400E-03	5.03600E-02
1-8			4.01611E+03	0.00000E+00	5.35184E-03	4.09500E-02	2.92500E-01
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 3, bandpass, linear fit)

DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
1-1	HI	LO	9.24095E+00	-9.30558E-01	1.97804E-04	5.90900E-04	1.59300E+00
1-2			5.10054E+00	-5.13630E-01	1.97565E-04	5.90900E-04	1.59300E+00
1-3			1.19013E+01	-1.19850E+00	1.97282E-04	5.90900E-04	1.59300E+00
1-4			4.72049E+00	-4.75355E-01	1.97683E-04	5.90900E-04	1.59300E+00
1-5			1.18013E+01	-1.18845E+00	1.97075E-04	5.90900E-04	1.59300E+00
1-6			4.85057E+00	-4.88485E-01	1.96858E-04	5.90900E-04	1.59300E+00
1-7			2.00020E+02	-2.01415E+01	1.98138E-04	5.90900E-04	1.59300E+00
1-8			4.20044E+01	-4.22984E+00	1.97709E-04	5.90900E-04	1.59300E+00
1-1	HI	HI	1.00011E-01	-1.00713E-02	1.97397E-04	5.90900E-04	1.59300E+00
1-2			5.50060E-02	-5.53925E-03	1.97351E-04	5.90900E-04	1.59300E+00
1-3			1.28014E-01	-1.28911E-02	1.97547E-04	5.90900E-04	1.59300E+00
1-4			5.00054E-02	-5.03565E-03	1.97397E-04	5.90900E-04	1.59300E+00
1-5			1.26014E-01	-1.26902E-02	1.97119E-04	5.90900E-04	1.59300E+00
1-6			5.10053E-02	-5.13625E-03	1.97680E-04	5.90900E-04	1.59300E+00
1-7			2.05020E+00	-2.06449E-01	1.98214E-04	5.90900E-04	1.59300E+00
1-8			4.60049E-01	-4.63273E-02	1.97570E-04	5.90900E-04	1.59300E+00
1-1	MED	LO	7.64607E+01	0.00000E+00	4.13072E-03	1.24000E-01	8.06100E-01
1-2			4.33221E+01	0.00000E+00	2.41812E-03	2.24700E-01	1.42900E+00
1-3			8.56132E+01	0.00000E+00	1.11518E-02	1.12200E-01	7.20600E-01
1-4			3.96118E+01	0.00000E+00	2.80515E-03	2.49300E-01	1.56700E+00
1-5			9.16161E+01	0.00000E+00	4.00900E-03	1.04700E-01	6.73900E-01
1-6			3.93271E+01	0.00000E+00	7.89901E-03	2.53600E-01	1.58100E+00
1-7			1.66104E+03	0.00000E+00	2.68353E-03	5.92200E-03	3.73200E-02
1-8			3.06200E+02	0.00000E+00	3.60119E-03	3.09200E-02	2.01200E-01
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	LO	7.38846E+02	0.00000E+00	2.16146E-02	1.38100E-01	2.03100E+00
1-2			4.09153E+02	0.00000E+00	6.01879E-04	2.46500E-01	2.17100E+00
1-3			8.39453E+02	0.00000E+00	1.66609E-02	1.21900E-01	2.27900E+00
1-4			3.71243E+02	0.00000E+00	4.36598E-03	2.73600E-01	2.39200E+00
1-5			8.91141E+02	0.00000E+00	2.44889E-02	1.15000E-01	2.15500E+00
1-6			3.74388E+02	0.00000E+00	6.49464E-03	2.74600E-01	2.38600E+00
1-7			1.52544E+04	0.00000E+00	9.91429E-03	6.59300E-03	1.58200E-01
1-8			2.80288E+03	0.00000E+00	2.98728E-03	3.57400E-02	8.61300E-01
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 5, bandpass, linear fit)

DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
1-1	HI	LO	4.70050E+00	-4.73345E-01	1.97572E-04	5.90900E-04	1.59300E+00
1-2			2.62027E+00	-2.63858E-01	1.97887E-04	5.90900E-04	1.59300E+00
1-3			5.70063E+00	-5.74074E-01	1.97235E-04	5.90900E-04	1.59300E+00
1-4			2.44027E+00	-2.45745E-01	1.97171E-04	5.90900E-04	1.59300E+00
1-5			5.90067E+00	-5.94225E-01	1.97075E-04	5.90900E-04	1.59300E+00
1-6			2.45028E+00	-2.46758E-01	1.96919E-04	5.90900E-04	1.59300E+00
1-7			9.20098E+01	-9.26551E+00	1.97514E-04	5.90900E-04	1.59300E+00
1-8			2.10022E+01	-2.11492E+00	1.97709E-04	5.90900E-04	1.59300E+00
1-1	HI	HI	5.15055E-02	-5.18668E-03	1.97471E-04	5.90900E-04	1.59300E+00
1-2			2.95031E-02	-2.97097E-03	1.97681E-04	5.90900E-04	1.59300E+00
1-3			6.30071E-02	-6.34508E-03	1.97119E-04	5.90900E-04	1.59300E+00
1-4			2.70029E-02	-2.71922E-03	1.97529E-04	5.90900E-04	1.59300E+00
1-5			6.50073E-02	-6.54648E-03	1.97123E-04	5.90900E-04	1.59300E+00
1-6			2.70029E-02	-2.71922E-03	1.97529E-04	5.90900E-04	1.59300E+00
1-7			9.70109E-01	-9.76943E-02	1.97145E-04	5.90900E-04	1.59300E+00
1-8			2.45026E-01	-2.46745E-02	1.97475E-04	5.90900E-04	1.59300E+00
1-1	MED	LO	3.76153E+01	0.00000E+00	6.88971E-03	1.31600E-01	6.84200E-01
1-2			2.16678E+01	0.00000E+00	5.06421E-03	2.31200E-01	1.19100E+00
1-3			3.99215E+01	0.00000E+00	9.31075E-03	1.21600E-01	6.41800E-01
1-4			1.96088E+01	0.00000E+00	5.30408E-03	2.56300E-01	1.31700E+00
1-5			4.42227E+01	0.00000E+00	8.62833E-03	1.10300E-01	5.79700E-01
1-6			1.90596E+01	0.00000E+00	6.37522E-03	2.64900E-01	1.35700E+00
1-7			7.68690E+02	0.00000E+00	9.28259E-03	6.50100E-03	3.35500E-02
1-8			1.52497E+02	0.00000E+00	6.48132E-03	3.15900E-02	1.67900E-01
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	LO	3.61336E+02	0.00000E+00	9.55926E-03	1.17700E-01	2.19700E+00
1-2			2.06561E+02	0.00000E+00	4.32410E-03	2.06700E-01	2.62000E+00
1-3			3.94388E+02	0.00000E+00	1.90992E-02	1.09000E-01	2.41600E+00
1-4			1.86299E+02	0.00000E+00	8.65719E-03	2.29400E-01	2.32800E+00
1-5			4.32396E+02	0.00000E+00	1.42712E-02	9.88200E-02	2.19900E+00
1-6			1.83914E+02	0.00000E+00	9.96345E-03	2.35500E-01	2.34700E+00
1-7			7.15619E+03	0.00000E+00	9.91052E-03	5.85000E-03	2.10900E-01
1-8			1.42175E+03	0.00000E+00	3.34997E-03	2.97100E-02	1.07600E+00
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 6, bandpass, linear fit)


DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
1-1	HI	LO	2.74029E+00	-2.75951E-01	1.97556E-04	5.90900E-04	1.59300E+00
			1.43015E+00	-1.44020E-01	1.97396E-04	5.90900E-04	1.59300E+00
			3.07035E+00	-3.09198E-01	1.97079E-04	5.90900E-04	1.59300E+00
			1.40015E+00	-1.40995E-01	1.97646E-04	5.90900E-04	1.59300E+00
			3.58042E+00	-3.60570E-01	1.96903E-04	5.90900E-04	1.59300E+00
			1.35015E+00	-1.35968E-01	1.96995E-04	5.90900E-04	1.59300E+00
			5.10051E+01	-5.13611E+00	1.98007E-04	5.90900E-04	1.59300E+00
			1.18013E+01	-1.18845E+00	1.97075E-04	5.90900E-04	1.59300E+00
1-1	HI	HI	2.85028E-02	-2.87014E-03	1.98150E-04	5.90900E-04	1.59300E+00
			1.70018E-02	-1.71211E-03	1.97481E-04	5.90900E-04	1.59300E+00
			3.20034E-02	-3.22278E-03	1.97547E-04	5.90900E-04	1.59300E+00
			1.75020E-02	-1.76257E-03	1.96884E-04	5.90900E-04	1.59300E+00
			3.75039E-02	-3.77662E-03	1.97761E-04	5.90900E-04	1.59300E+00
			1.40015E-02	-1.41000E-03	1.97258E-04	5.90900E-04	1.59300E+00
			5.30059E-01	-5.33787E-02	1.97195E-04	5.90900E-04	1.59300E+00
			1.25014E-01	-1.25892E-02	1.97349E-04	5.90900E-04	1.59300E+00
1-1	MED	LO	2.09710E+01	0.00000E+00	2.34889E-02	1.08100E-01	6.76200E-01
			1.17344E+01	0.00000E+00	1.97782E-02	2.01900E-01	1.22000E+00
			2.17983E+01	0.00000E+00	1.91173E-02	1.04800E-01	6.53400E-01
			1.11109E+01	0.00000E+00	2.06169E-02	2.12000E-01	1.29100E+00
			2.60926E+01	0.00000E+00	1.77302E-02	8.87200E-02	5.47200E-01
			1.10344E+01	0.00000E+00	3.33182E-02	4.05000E-01	1.87000E+00
			4.13411E+02	0.00000E+00	3.41095E-02	9.18700E-03	4.79800E-02
			8.49784E+01	0.00000E+00	2.21705E-02	4.85000E-02	2.38800E-01
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	LO	2.37092E+02	0.00000E+00	5.11210E-02	1.31600E-01	2.37400E+00
			1.25615E+02	0.00000E+00	3.61761E-02	1.76800E-01	2.33900E+00
			2.46703E+02	0.00000E+00	5.46204E-02	1.26100E-01	2.29800E+00
			1.19401E+02	0.00000E+00	4.34231E-02	1.82600E-01	2.46300E+00
			2.91423E+02	0.00000E+00	5.23084E-02	1.39300E-01	1.94100E+00
			1.12079E+02	0.00000E+00	3.31469E-02	2.71300E-01	2.00200E+00
			4.63155E+03	0.00000E+00	4.69627E-02	1.48200E-02	4.47100E-01
			9.07261E+02	0.00000E+00	5.90044E-02	3.45300E-02	2.26300E+00
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 1, filter 7, bandpass, linear fit)


DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
1-1	HI	LO	4.93058E+00	-4.96540E-01	1.96893E-04	5.90900E-04	1.59300E+00
1-2			2.59029E+00	-2.60854E-01	1.97106E-04	5.90900E-04	1.59300E+00
1-3			6.10067E+00	-6.14355E-01	1.97291E-04	5.90900E-04	1.59300E+00
1-4			2.45028E+00	-2.46758E-01	1.96919E-04	5.90900E-04	1.59300E+00
1-5			6.28071E+00	-6.32495E-01	1.97080E-04	5.90900E-04	1.59300E+00
1-6			2.48528E+00	-2.50278E-01	1.97120E-04	5.90900E-04	1.59300E+00
1-7			1.00010E+02	-1.00708E+01	1.98138E-04	5.90900E-04	1.59300E+00
1-8			2.27022E+01	-2.28602E+00	1.98375E-04	5.90900E-04	1.59300E+00
1-1	HI	HI	5.20054E-02	-5.23694E-03	1.97785E-04	5.90900E-04	1.59300E+00
1-2			2.87031E-02	-2.89046E-03	1.97414E-04	5.90900E-04	1.59300E+00
1-3			6.35065E-02	-6.39504E-03	1.97887E-04	5.90900E-04	1.59300E+00
1-4			2.53027E-02	-2.54804E-03	1.97436E-04	5.90900E-04	1.59300E+00
1-5			6.53071E-02	-6.57660E-03	1.97350E-04	5.90900E-04	1.59300E+00
1-6			2.65027E-02	-2.66882E-03	1.97733E-04	5.90900E-04	1.59300E+00
1-7			1.05011E+00	-1.05746E-01	1.97716E-04	5.90900E-04	1.59300E+00
1-8			2.40026E-01	-2.41713E-02	1.97319E-04	5.90900E-04	1.59300E+00
1-1	MED	LO	4.02599E+01	0.00000E+00	8.52661E-03	7.12500E-02	2.64800E-01
1-2			2.22169E+01	0.00000E+00	5.83285E-03	1.30000E-01	4.80900E-01
1-3			4.40717E+01	0.00000E+00	6.76410E-03	6.50800E-02	2.41900E-01
1-4			1.98978E+01	0.00000E+00	5.45587E-03	1.44500E-01	5.36200E-01
1-5			4.77429E+01	0.00000E+00	6.33491E-03	5.99500E-02	2.23200E-01
1-6			1.98131E+01	0.00000E+00	1.25351E-02	1.47800E-01	1.56200E+00
1-7			8.26340E+02	0.00000E+00	5.55579E-03	3.52800E-03	3.73800E-02
1-8			1.57822E+02	0.00000E+00	1.19112E-02	1.76200E-02	1.94800E-01
1-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-1	LO	LO	3.95411E+02	0.00000E+00	4.25188E-02	4.12300E-02	2.11700E+00
1-2			2.15415E+02	0.00000E+00	7.30950E-03	7.50800E-02	2.17200E+00
1-3			4.34721E+02	0.00000E+00	4.95090E-02	3.74800E-02	1.92600E+00
1-4			1.93037E+02	0.00000E+00	2.57777E-02	8.22200E-02	2.42500E+00
1-5			4.65179E+02	0.00000E+00	4.67937E-02	3.53400E-02	1.80100E+00
1-6			1.92070E+02	0.00000E+00	4.97299E-03	2.92000E-01	2.44300E+00
1-7			8.08514E+03	0.00000E+00	3.38883E-02	6.94700E-03	4.71200E-01
1-8			1.50470E+03	0.00000E+00	1.28024E-02	3.69300E-02	2.12600E+00
1-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-6			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-7			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
1-8			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00

CIRRIS 1A Radiometer Linearity Coefficients
(focal plane 2, bandpass, linear fit)

DET	BIAS	GAIN	A1	A2	S.D.	MIN. VOLT.	MAX. VOLT.
2-1	HI	LO	7.41184E+01	0.00000E+00	5.88644E-02	6.32100E-04	6.68600E-02
2-2			6.88387E+01	0.00000E+00	5.85583E-02	2.58900E-03	7.09700E-02
2-3			9.80041E+01	0.00000E+00	5.52881E-02	1.64700E-04	5.03700E-02
2-4			6.90045E+02	0.00000E+00	5.53125E-02	3.36700E-04	7.23500E-03
2-5			4.39361E+02	0.00000E+00	4.58320E-02	3.90800E-05	1.12400E-02
2-1	HI	HI	7.23608E-01	0.00000E+00	5.86193E-02	1.15300E-02	1.19700E+00
2-2			6.90780E-01	0.00000E+00	8.50120E-03	1.08200E+00	2.16200E+00
2-3			9.76887E-01	0.00000E+00	4.74408E-02	1.65800E-02	8.78600E-01
2-4			6.86356E+00	0.00000E+00	5.43467E-02	6.78200E-03	7.22400E-01
2-5			4.41210E+00	0.00000E+00	5.66832E-02	4.64700E-03	6.46900E-01
2-1	MED	LO	8.12429E+02	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-2			8.43696E+02	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-3			1.20446E+03	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-4			6.68579E+03	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-5			3.67135E+03	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-1	MED	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-1	LO	LO	7.57704E+03	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-2			7.06154E+03	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-3			9.33072E+03	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-4			5.96692E+04	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-5			3.10857E+04	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-1	LO	HI	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-2			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-3			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-4			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00
2-5			0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00




Filter 0






Relative spectral response for radiometer detector 1-4.


Filter 1




Relative spectral response for radiometer detector 1-4.




Relative spectral response for radiometer detector 1-4 (cont).




Relative spectral response for radiometer focal plane 2.




Radiometer out-of-band rejection, focal plane 1, filter 0.




Radiometer out-of-band rejection, focal plane 1, filter 1.




Radiometer out-of-band rejection, focal plane 1, filter 2.





Radiometer out-of-band rejection, focal plane 1, filter 3.




Radiometer out-of-band rejection, focal plane 1, filter 5.



Radiometer out-of-band rejection, focal plane 1, filter 7.




Radiometer out-of-band rejection, focal plane 2.



Gain = HI ($\times 100$), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI ($\times 100$), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-1.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-2.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-3.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-4.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-5.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-6.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-7.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 1-8.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 2-1.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 2-2.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 2-3.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

RMS noise history for radiometer detector 2-4.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off




Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.

Chopper On

RMS noise history for radiometer detector 2-5.




Chopper Off




Chopper On

Offset history for radiometer detector 1-1.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 1-2.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 1-3.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 1-4.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 1-5.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off




Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.

Chopper On

Offset history for radiometer detector 1-6.




Chopper Off




Chopper On

Offset history for radiometer detector 1-7.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off




Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.

Chopper On

Offset history for radiometer detector 1-8.




Chopper Off




Chopper On

Offset history for radiometer detector 2-1.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 2-2.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 2-3.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper On

Offset history for radiometer detector 2-4.



Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.


Chopper Off






Gain = HI (x100), Bias = HHHH, FW 4, Sept 1988 - Feb 1992.

Chopper On

Offset history for radiometer detector 2-5.




Radiometer noise flux versus band pass for filter 0
(chopper on, extended area source - order on curve labels is bias - gain).





Detector noise flux versus band pass for filter 0

(chopper on, extended area source - order on curve labels is bias - gain).




Radiometer noise flux versus band pass for filter 1
(chopper on, extended area source - order on curve labels is bias - gain).






Radionometer noise flux versus band pass for filter 2
(chopper on, extended area source - order on curve labels is bias - gain).




BAND PASS FLUX [W/(cm²*sr)]
Detector 1-5




BAND PASS FLUX [W/(cm²*sr)]
Detector 1-6


Plot 1-7: Radiometer noise flux versus band pass flux for filter 2 (chopper on, extended area source - order on curve labels is bias - gain).




Radiometer noise flux versus band pass for filter 3
(chopper on, extended area source - order on curve labels is bias - gain).




Detector 1-5



Detector 1-6




Detector 1-7




Detector 1-8


Radiometer noise flux versus band pass for filter 3
(chopper on, extended area source - order on curve labels is bias - gain).




Detector 1-1



Detector 1-3







Detector 1-2




Detector 1-4


Radiometer noise flux versus band pass for filter 5
(chopper on, extended area source - order on curve labels is bias - gain).




Radiometer noise flux versus band pass for filter 5
(chopper on, extended area source - order on curve labels is bias - gain).




Radionometer noise flux versus band pass for filter 6
(chopper on, extended area source - order on curve labels is bias - gain).







Radiometer noise flux versus band pass for filter 7
(chopper on, extended area source - order on curve labels is bias - gain).




Detector 1-6




Detector 1-8
 Radiometer noise flux versus band pass for filter 7
 (chopper on, extended area source - order on curve labels is bias - gain).




Detector 1-5




Detector 1-7




Radiometer noise flux versus band pass
(chopper on, extended area source - order on curve labels is bias - gain).





Radiometer noise flux versus band pass
 (chopper on, extended area source - order on curve labels is bias - gain).




RMS noise history for interferometer detector 1.



RMS noise history for interferometer detector 2.





RMS noise history for interferometer detector 5.

